



*TopCure meets ASTM C171

MSDS can be downloaded at transhield-usa.com/topcure

DIRECTIONS FOR USE

1. Apply immediately after concrete has achieved surface strength
2. Completely FLOOD the slab with water. Water is critical to the material's performance.
3. Begin rolling out TopCure along the edge of the slab while spraying the inner fabric layer with water as it unwinds
4. Be sure to completely saturate the fabric side
5. Slowly continue unrolling and saturating with water. The material should "float" on the water.
6. Overlap edges at least 4"
7. Do not let the material crease. Creases will cause tiger stripes.
8. Continue process until slab is covered For outdoor use: Weigh down edges and seams with rebar, 2x4s, or any similar weight to keep air from getting underneath
9. Remove after 7-days and dispose (folds up easily)

HELPFUL TIPS and TIDBITS

1. Water. Water. Water
2. Thread a long rope through the core and slowly pull across the slab like a wedding runner.
3. Spraying the top surface will add weight to the top surface and can aide in keeping the material down should wind be a concern. Weights on edges and seams are still recommended.
4. TopCure is durable enough to withstand light to moderate construction traffic.
5. TopCure is a co-mingled product. It is recyclable as long as the film is separated from the nonwoven.

Any questions, call Transhield at 574-266-4118

TopCure® is a registered trademark of Transhield, Inc.

www.transhield-usa.com