

TRANSHIELD COVER INSTALLATION FOR BOAT MANUFACTURERS

Preparing your cover for over the road transit



1 PAD PROTRUSIONS

Ensure all sharp corners and any protruding points are padded or blunted with tape, Styrofoam, etc.



2 CENTER COVER

After rolling out the cover make sure it drapes evenly on both sides of the boat; the cover should look symmetrical when viewed from the front and back.



3 SECURE COVER

Pull out all slack from perimeter rope and tie off to secure. Do the same with all belly bands and any other securement points on the cover.



4 CHECK CHINE COVERAGE

Ensure there is at least 6 to 12 inches of material tucked under the chine. For larger boats, there should be 8 to 12 inches or more.



5 HEAT SHRINK

Heat shrink the cover evenly on all panels of the cover. For instructions on how to shrinkwrap, check out our instructional videos on YouTube.



6 RETIGHTEN

After heat shrinking, go back and re-tighten *all* securement points on the cover.



7 REPAIR & REINFORCE

Perform a quick walkaround and repair any burn holes caused during heat shrinking with shrink tape, and tape over any protruding stress points on the cover.



This document serves as a general guide for installing a Transshield cover and is **not intended to replace specific installation instructions** for your particular boat. For detailed instructions tailored to your needs, please contact your Transshield Sales Representative or Account Manager.

CONTACT US

GENERAL@TRANSHIELD-USA.COM
TRANSHIELD-USA.COM